

CORAGGIO

Pre-Trimmed, Non-Woven Backing

MADE IN JAPAN

DESIGN
WAVES

ITEM #
CW10028
CW10029
CW10030

PATTERN SPECIFICATIONS
PRETRIMMED 36" WIDE
STRAIGHT MATCH

coraggio.com

Coraggio Distribution Center, 8805 Air Park West Drive, Charlotte, NC 28214, USA

Hanging instructions overleaf



California Proposition 65 Compliant
www.P65warnings.ca.gov



CORAGGIO

INSTRUCTIONS FOR HANGING CORAGGIO WAVES WALLCOVERING NON-WOVEN BACKING, PRE-TRIMMED

Before you start to hang: Examine goods to make certain pattern and color is accurate and as ordered. Have all associated products in your possession to insure correct color match. Review each bolt label and make certain the lot number is the same for all bolts received. Review item numbers to ensure all are the same. Install all wallcovering under adequate lighting and heated conditions that will exist when space is occupied.

Important: If after hanging the first three strips, you notice any defects in the material, STOP work and notify your supplier. NO ALLOWANCES FOR LABOR OR MATERIAL WILL BE MADE PAST THIS POINT.

Preparation: Our quality textile wallcovering may be applied to any smooth, clean, dry surface. Remove old wallcovering completely and remove remaining adhesive. Cracks should be filled with spackling compound and sanded smooth. Glossy or enamel walls should be lightly sanded and washed with common household detergent. Prime all walls with a Universal Pre-Wallcovering primer.

Mildew: Mold and mildew require moisture to grow, therefore it is important that any excessive moisture in the wall be corrected prior to installation. On old walls where mold spores may be present, they should be washed with a detergent solution or cleaned using

a vacuum with a HEPA filter. This should be followed by treating with a chlorine bleach solution of 1 cup bleach to 4 quarts water to kill any remaining spores. Rinse clean and dry.

Adhesives: This wallcovering requires the use of a heavy duty clear premixed vinyl adhesive. Dilution of the adhesive should be avoided. As with the nature of all textiles and fabrics, extra care should be taken to keep all adhesive off the face of the material.

Application: Hang the first strip parallel to a plumb line. Cut strips a few inches longer than required to allow for trimming at ceiling and baseboard.

Apply the recommended adhesive to the back of the first strip using a paint roller. Work the adhesive to cover the back completely, especially near the edges. Fold or “book” each end toward the middle, pasted sides together, aligning the edges carefully so they do not dry out. Fold or roll the booked strip loosely and set aside for five to eight minutes. Unfold your first strip halfway and install at the plumb line, unfold the bottom of the strip, and keep aligned to the plumb line. Smooth with a soft bristle brush only to remove air pockets or paste lumps working toward the uncovered wall assuring complete adhesion. Trim the ceiling, baseboard, windows, and doors with a single edge razor blade changing razor blades often.

Note: Use strips in exact order as they are cut from the roll. Straight hang or reverse strips to reduce shading at the seams as needed. Fill in over doors and windows with strips cut in consecutive order from the roll. Hang only one strip at a time.

To clean: All stains should be treated as soon as possible with clean water, by using a soft white cloth. For most stains a commonly available water-soluble household product can be used, being careful not to flood the surface. Abrasive rubbing of spots should be avoided so that discoloration does not appear. More care should be taken in cleaning any dark colors due to the possibility of causing light spots to appear. Testing first in an inconspicuous area is recommended.

Important: These wallcoverings have been manufactured to the highest quality standards. However, it should be noted that some items by their nature require additional care in handling and installing to provide an acceptable wall finish. As with all natural fiber materials, irregularities in weave and coloration are normal occurrences that enhance the hand-made appearance. This provides a look that cannot be duplicated by conventional machine-made wallcoverings.