

CORAGGIO

Pre-Trimmed, Non-Woven Backing
MADE IN KOREA

DESIGN	ITEM #
DEDALO	CW10075
	CW10076
	CW10077
	CW10078

PATTERN SPECIFICATIONS
PRETRIMMED 36" WIDE (91.44 CM)
RANDOM MATCH REVERSE HANG
JUTE AND PAPER ON NON-WOVEN

coraggio.com

Coraggio Distribution Center, 8805 Air Park West Drive, Charlotte, NC 28214, USA

Hanging instructions overleaf

California Proposition 65 Compliant
www.P65warnings.ca.gov



CORAGGIO

INSTRUCTIONS FOR HANGING CORAGGIO DEDALO WALLCOVERING NON-WOVEN BACKING, STRIPPABLE, UNPASTED, PRE-TRIMMED

Before you start to hang: Examine goods to make certain pattern and color is accurate and as ordered. Have all associated products in your possession to insure correct color match. Review each bolt label and make certain the lot number is the same for all bolts received. Review item numbers to ensure all are the same. Install all wallcovering under adequate lighting and heated conditions that will exist when space is occupied.

Important: If after hanging the first three strips, you notice any defects in the material, STOP work and notify your supplier. NO ALLOWANCES FOR LABOR OR MATERIAL WILL BE MADE PAST THIS POINT.

Preparation: Our quality specialty wallcovering may be applied to any smooth, clean, dry surface. Remove old wallcovering completely and remove remaining adhesive. Cracks should be filled with spackling compound and sanded smooth. Glossy or enamel walls should be lightly sanded and washed with common household detergent. Prime all walls with a Universal Pre-Wallcovering primer.

Mildew: Mold and mildew require moisture to grow, therefore it is important that any excessive moisture in the wall be corrected prior to installation. On old walls where mold spores may be present, they should be washed with a detergent solution or cleaned using

a vacuum with a HEPA filter. This should be followed by treating with a chlorine bleach solution of 1 cup bleach to 4 quarts water to kill any remaining spores. Rinse clean and dry.

Adhesives: This wallcovering requires the use of a heavy duty clear premixed vinyl adhesive. Dilution of the adhesive should be avoided. As with the nature of all delicate wallcoverings, extra care should be taken to keep all adhesive off the face of the material.

Apply the recommended adhesive to the back of the first strip using a paint roller. Work the adhesive to cover the back completely, especially near the edges. Pasted sheets should be booked for 2 to 5 minutes, to allow the paper to absorb moisture and relax.

Before installation, first the rolls and then the strips must be sorted by color intensity, from dark to light and hang them in the sequence the sorting has created. In some cases, the bolts may come with a sequence number printed on the label for sorting assistance. Specialty wallcoverings will always panel to some extent, and this is not a defect but a phenomenon of nature. With random designs reverse hang the strips, this will reduce most of the paneling from sudden shade shifts to pleasant undulations of color.

Application: Hang the first strip parallel to a plumb line. Cut strips a few inches longer than required to allow for trimming at ceiling and baseboard.

Note: The decorative inks used for this wallcovering is made of water or alcohol dyes and is sensitive to water. Do not allow paste or water to stain the front of the wallcovering. Do not handle with wet hands. Smoothing of the panels should be done with a soft brush only. Do not use plastic or metal smoothers. Do not use a seam roller.

Cleaning: Use a vacuum with a soft bristle brush to clean the surface. Water should not be applied at any time for cleaning.

Important: These wallcoverings have been manufactured to the highest quality standards. However, it should be noted that some items by their nature require additional care in handling and installing to provide an acceptable wall finish. As with all natural fiber materials, irregularities in weave and coloration are normal occurrences that enhance the hand-made appearance. This provides a look that cannot be duplicated by conventional machine-made wallcoverings.